cozysewpatterns

Print this Calibration Test page first!

Size: Height: 167.75, Bust: 114.25, Waist: 99, Hips: 120.75
SIZE 18

Notes

How to print

Printing


Once your Calibration Test Page has been printed, measure the 4”x 4” (10cm) scale box with a ruler. If the lengths match, you can confidently print your pattern. If the rulers do not match, set your print settings to 100% or Actual and retry.

Cutting

Your printouts will always have a dashed border to perfectly match your sheets. Cut off the right edge of each page. Be careful not to cut beyond the dashed mark, otherwise your patterns will not align accurately.

Tapping

Group each sheet by the second number marked on each pate i.e. in a group 1, there are: 1/1, 2/1, 3/1, 4/1, etc. In a group 2: 1/2, 2/2 etc. 2. Place page 1/1 on top of the page 2/1, overlapping the right side edge. Match corners and crosses and secure with a pin or tape. Then use a scotch tape to permanently attach the sheets together.



SIZE 18
Seam Allowance: 1 (3/8 in)

Pattern pieces:


1. "PANTS FRONT", MAIN FABRIC: Cut 2
2. "PANTS BACK", MAIN FABRIC: Cut 2
3. "WAISTBAND", MAIN FABRIC: Cut 1
4. "POCKET BAG", LINING: Cut 4


Pattern Specs (Circumferences are divided by 2):


1. Hem max 3.00 none (1 1/8 in)
2. Seam allowance max 2.00 none (3/4 in)
3. Seam allowance poc max 3.00 none (1 1/8 in)
4. Stretch factor 0.92 none (3/8 in)
5. Stretch factor horizontal 0.92 none (3/8 in)
6. Stretch factor vertical 1.00 none (3/8 in)
7. Pocket entry length 13.14 cm (5 1/8 in)
8. Waist to pocket length 6.23 cm (2 1/2 in)
9. Low hips 58.31 cm (23 in)
10. Thigh 36.91 cm (14 1/2 in)
11. Knee 29.72 cm (11 3/4 in)
12. Bottom opening 24.92 cm (9 3/4 in)
13. Front rise 32.32 cm (12 3/4 in)
14. Back rise 43.68 cm (17 1/4 in)
15. Crotch height 30.49 cm (12 in)
16. Inseam length 69.76 cm (27 1/2 in)
17. Pants side seam length 100.73 cm (39 5/8 in)
18. Pocket bag height 24.51 cm (9 5/8 in)
19. Waistband width 3.30 cm (1 1/4 in)
20. Waistband elastic width 3.30 cm (1 1/4 in)
21. Waistband length 56.11 cm (22 1/8 in)
22. Waistband elastic length 81.60 cm (32 1/8 in)

cozysewpatterns

Paper Size: A4;
Print Actual Size (100% Scale);








2


PANTS BACK


MAIN FABRIC: Cut 2





PANTS FRONT


MAIN FABRIC: Cut 2









4
POCKET BAG
LINING: Cut 4






















4/1











5/1


SIDE SEAM

WAISTBAND


MAIN FABRIC: Cut 1


3


5/2



GTH 32 1/8" (81.6) cm WIDTH 1 1/4" (3.3) cm


5/4
FOLD
SIDE SEAM


CENTER FRONT
WAISTLINE


SIDE
SEAM