
cozysewpatterns

Print this Calibration Test page first!

Size: Height: 167.75, Bust: 124.25, Waist: 110.5, Hips: 130.75
SIZE 22

Notes



How to print

Printing

Once your Calibration Test Page has been printed, measure the 4”x 4” (10cm) scale box with a ruler. If the lengths match, you can confidently print your pattern. If the rulers do not match, set your print settings to 100% or Actual and retry.

Cutting

Your printouts will always have a dashed border to perfectly match your sheets. Cut off the right edge of each page. Be careful not to cut beyond the dashed mark, otherwise your patterns will not align accurately.

Tapping

Group each sheet by the second number marked on each pate i.e. in a group 1, there are: 1/1, 2/1, 3/1, 4/1, etc. In a group 2: 1/2, 2/2 etc. 2. Place page 1/1 on top of the page 2/1, overlapping the right side edge. Match corners and crosses and secure with a pin or tape. Then use a scotch tape to permanently attach the sheets together.

SIZE 22
Seam Allowance: 1 (3/8 in)

Pattern pieces:


1. "PANTS FRONT", MAIN FABRIC: Cut 2
2. "PANTS BACK", MAIN FABRIC: Cut 2
3. "WAISTBAND FRONT", MAIN FABRIC: Cut 1
4. "WAISTBAND BACK", MAIN FABRIC: Cut 1
5. "POCKET BAG", LINING: Cut 4


Pattern Specs (Circumferences are divided by 2):


1. Hem max 3.00 none (1 1/8 in)
2. Seam allowance max 2.00 none (3/4 in)
3. Seam allowance poc max 3.00 none (1 1/8 in)
4. Stretch factor 0.92 none (3/8 in)
5. Stretch factor horizontal 0.92 none (3/8 in)
6. Stretch factor vertical 1.00 none (3/8 in)
7. Pocket entry length 13.77 cm (5 3/8 in)
8. Waist to pocket length 6.31 cm (2 1/2 in)
9. Low hips 62.99 cm (24 3/4 in)
10. Thigh 39.50 cm (15 1/2 in)
11. Knee 32.20 cm (12 5/8 in)
12. Bottom opening 26.48 cm (10 3/8 in)
13. Front rise 33.92 cm (13 3/8 in)
14. Back rise 46.50 cm (18 1/4 in)
15. Crotch height 31.79 cm (12 1/2 in)
16. Inseam length 68.37 cm (26 7/8 in)
17. Pants side seam length 100.44 cm (39 1/2 in)
18. Pocket bag height 25.48 cm (10 in)
19. Waistband width 3.30 cm (1 1/4 in)
20. Waistband elastic width 3.30 cm (1 1/4 in)
21. Waistband length 60.72 cm (23 7/8 in)
22. Waistband elastic length 90.80 cm (35 3/4 in)

cozysewpatterns

Paper Size: LETTER;
Print Actual Size (100% Scale);








2


PANTS BACK


MAIN FABRIC: Cut 2




PANTS FRONT


MAIN FABRIC: Cut 2

















3/2





3/4




















5/2





POCKET BAG
LINING: Cut 4



5


4
WAISTBAND BACK
MAIN FABRIC: Cut 1
SIDE SEAM
3
WAISTBAND FRONT
MAIN FABRIC: Cut 1
FOLD
SIDE SEAM
6/1

6/2


WAISTLINE
CENTER BACK
WAISTLINE
WAISTLINE
CENTER FRONT
WAISTLINE


SIDE
SEAM


FOLD
SIDE SEAM

6/5