
cozysewpatterns

Print this Calibration Test page first!

Size: Height: 144.75, Bust: 70, Waist: 59.25, Hips: 75
SIZE 10 145

Notes



How to print

Printing

Once your Calibration Test Page has been printed, measure the 4”x 4” (10cm) scale box with a ruler. If the lengths match, you can confidently print your pattern. If the rulers do not match, set your print settings to 100% or Actual and retry.

Cutting

Your printouts will always have a dashed border to perfectly match your sheets. Cut off the right edge of each page. Be careful not to cut beyond the dashed mark, otherwise your patterns will not align accurately.

Tapping

Group each sheet by the second number marked on each pate i.e. in a group 1, there are: 1/1, 2/1, 3/1, 4/1, etc. In a group 2: 1/2, 2/2 etc. 2. Place page 1/1 on top of the page 2/1, overlapping the right side edge. Match corners and crosses and secure with a pin or tape. Then use a scotch tape to permanently attach the sheets together.

cozysewpatterns

SIZE 10 145
Seam Allowance: 1 (3/8 in)

Pattern pieces:


1. "PANTS FRONT", MAIN FABRIC: Cut 2
2. "PANTS BACK", MAIN FABRIC: Cut 2
3. "POCKET BAG", LINING: Cut 4


Pattern Specs (Circumferences are divided by 2):

1. Hem max 3.00 none (1 1/8 in)
2. Seam allowance max 2.00 none (3/4 in)
3. Seam allowance poc max 3.00 none (1 1/8 in)
4. Stretch factor 0.92 none (3/8 in)
5. Stretch factor horizontal 0.92 none (3/8 in)
6. Stretch factor vertical 1.00 none (3/8 in)
7. Pocket entry length 10.00 cm (3 7/8 in)
8. Waist to pocket length 5.06 cm (2 in)
9. Low hips 36.91 cm (14 1/2 in)
10. Thigh 24.97 cm (9 7/8 in)
11. Knee 25.03 cm (9 7/8 in)
12. Bottom opening 25.57 cm (10 1/8 in)
13. Front rise 16.94 cm (6 5/8 in)
14. Back rise 26.24 cm (10 3/8 in)
15. Crotch height 21.58 cm (8 1/2 in)
16. Inseam length 65.10 cm (25 5/8 in)
17. Pants side seam length 80.83 cm (31 7/8 in)
18. Waistband elastic length 52.91 cm (20 7/8 in)
19. Waistband elastic width 4.00 cm (1 5/8 in)
20. Pocket bag height 19.63 cm (7 3/4 in)

cozysewpatterns

Paper Size: LETTER;
Print Actual Size (100% Scale);








PANTS BACK

MAIN FABRIC: Cut 2


FOLD
) 7/8" (52.91)cm WIDTH 1 5/8" (4)cm









3/1


3/2






FOLD






1
PANTS FRONT
MAIN FABRIC: Cut 2
5/1


3
POCKET BAG
LINING: Cut 4
5/2









8/2

